



**Because keeping you safe is our top priority...  
Please take a moment to read through the following  
care and use instructions for your new glasses.**

**1 The NoCry glasses**

Anti-scratch  
Anti-fogging

The lenses have anti-scratch and anti-fogging treatment.

**2 Cleaning your glasses**

Clean the glasses only using a dry or water-moistened soft micro-fiber cloth. Do not use chemicals.

**3 Storing your glasses**

When not in use, store the glasses in a protective case.

[nocry.com](http://nocry.com)

**4 The glasses are highly adjustable**

Temple length & angle  
Nosepiece

Adjust the glasses so that they will fit your face securely and comfortably before each use.

**5 Fit glasses correctly to avoid condensation**

No airflow = Condensation  
Airflow

If there is condensation building up on the lenses try to adjust the temple angle.

**6 Carefully assess your working environment**

**IF IN DOUBT**

Occupational Safety Professional or Industrial Hygienist

Make sure that the glasses are the most suitable means of protection from potential threats you are likely to be exposed to in your working environment.

**7 Contact us**

[wecare@nocry.com](mailto:wecare@nocry.com)

Feel free to contact us. We're always here to help.

## HOW DO YOU LIKE YOUR NEW NOCRY SAFETY GLASSES?

Help customers just like you make better choices by sharing an honest review of your experience on or

Your feedback helps us serve you better and it helps others choose the best products.

To leave us a review on **Amazon** > go to **Orders** > **Write a product review**  
To leave us a review on **Trustpilot** > **search NoCry** > **Write a review**